

JOTTO DESK®

Toll Free 877-455-6886

www.jottodesk.com

CONTOUR CONSOLE

Patented Product



YOU HAVE ORDERED ONE OF THE FOLLOWING CONSOLES:		
Qty	Order #	Description
1	425-6019	10" Contour Console - Crown Victoria (425-6008)
1	425-6026	12" Contour Console - Crown Victoria (425-6028)

PLUS

Qty	Part #	Description
1	425-1418	24" Extruded "No Holes" Floor Plate
2	425-6580	Floor mounting plate leg - lower section
2	425-6577	Floor mounting plate leg - upper section
8	000-1110	5/16-18 x 1" hex head bolt - grade 5
8	000-1230	5/16-18 nylock nut
8	000-1231	5/16" flat washer
1	425-1571-00	Adjustable leveler guide
20	000-1449	Phillips screws
10"-12"	requested	Faceplates

(Call 877.455.6886 ext.6425 for assistance)

CONTOUR CONSOLE - INSTALLATION INSTRUCTIONS (Contour Console with faceplates & floor plate)

- STEP 1:** Check to see that you have all of the parts listed above.
- STEP 2:** Remove front inside driver and passenger seat rail bolts and loosen respective outside seat bolts.
- STEP 3:** Place floor plate legs, 425-6580, assembled with the upper portion, 425-6577, underneath seat rails and align leg holes with seat rail holes. *NOTE: Loosening the two nuts attaching the leg pieces together allows for height adjustment of floor plate.*
- STEP 4:** Screw the leveler, 425-1571-00, through the bottom of floor plate till post is flush on top. Position floor plate between seats with the leveler towards the back.
- STEP 5:** Slide two provided hex head bolts down each side rail of floor plate, 425-1417. Align the bolts with the holes located at the top of the mounting legs. Using the provided washers and nylock nuts, secure the floor plate to the legs. Make necessary adjustments to the height of floor plate (both the legs and the leveler) and tighten *ALL* bolts.
- STEP 6:** Remove ash tray assembly.
- STEP 7:** Insert hex head bolts into the outside slots on top of the floor plate, two on each side. (These will be used to secure the console to the floor plate)
- STEP 8:** Position your console on top of the floor plate, with bolts (step 6) inserted through slots located at the bottom of the console. Slide console up against ash tray area of the dash.
- STEP 9:** Using provided washers and nylock nuts, secure console to the floor plate.
- STEP 10:** Feed communications wiring through the back of the console.
- STEP 11:** Mount communications equipment to provided faceplates, connect wires to the equipment and attach to the front of console with phillips screws.

CONTOUR CONSOLE - INSTALLATION INSTRUCTIONS (Contour Console with faceplates only)

- STEP 1:** Check to see that you have all of the parts listed.
- STEP 1:** Remove ash tray assembly.
- STEP 2:** Mount Console to your mounting surface as desired.
- STEP 3:** Mount communications equipment to provided faceplates, connect wires to the equipment and attach to the front of the console with phillips screws.

YOU HAVE ORDERED ONE OF THE FOLLOWING CONSOLES:		
Qty	Order #	Description
1	425-6008	10" Contour Console - Crown Victoria
1	425-6028	12" Contour Console - Crown Victoria

PLUS

Qty	Part #	Description
20	000-1449	Phillips screws
10"-12"	requested	Faceplates